

## **Test Procedure**

Equipment used: Pico Technology TC-08 Data Logger, Type "J" thermocouples

- 1. Add bath water to tub at 100°F
- 2. Place thermocouple into bath water located approximately 6 inches below water surface
- 3. Start data logger recording temperatures every minute.
- 4. Run test for two hours and record data on Excel spreadsheet