

Installation Instructions

- 1. Mount the **Twist n' Flow** control in a suitable location by drilling a 1-3/8" diameter hole in the tub.
- 2. Silicone the flange of the control and assemble the nut hand tight.
- 3. Drill a 1/8" diameter hole through the port above the pump inlet (Fig. 1).
- 4. Install the brass fitting with o-ring into the port using a 9/16" socket or wrench until the flange of the fitting is flush with the port - DO NOT OVER-TIGHTEN!
- 5. Attach one end of the tubing to the control or the brass fitting.
- 6. Cut the tubing to length so that it does not sag and trap water (Fig. 2).
- Attach the other end of the tubing. 7.



Figure 1

P/N 900105 REV A





- 1. Mount the *Twist n' Flow* control in a suitable location by drilling a 1-3/8" diameter hole in the tub.
- 2. Silicone the flange of the control and assemble the nut hand tight.
- 3. Drill a 1/8" diameter hole through the port above the pump inlet (Fig. 1).
- 4. Install the brass fitting with o-ring into the port using a 9/16" socket or wrench until the flange of the fitting is flush with the port - DO NOT OVER-**TIGHTEN!**
- 5. Attach one end of the tubing to the control or the brass fitting.
- 6. Cut the tubing to length so that it does not sag and trap water (Fig. 2).
- 7. Attach the other end of the tubing.





P/N 900105 REV A

P/N 900105 REV Figure 1

NuWhirl

nut hand tight.

TIGHTEN!

brass fitting.

trap water (Fig. 2).

the pump inlet (Fig. 1).

2.

3.

4.

7.

Drill Ø 1/8

Figure 2

Twist n' Flow

Installation Instructions

1. Mount the **Twist n' Flow** control in a suitable loca-

tion by drilling a 1-3/8" diameter hole in the tub.

Drill a 1/8" diameter hole through the port above

Install the brass fitting with o-ring into the port

5. Attach one end of the tubing to the control or the

6. Cut the tubing to length so that it does not sag and

Attach the other end of the tubing.

using a 9/16" socket or wrench until the flange of

the fitting is flush with the port - DO NOT OVER-

Correct

Incorrect

Silicone the flange of the control and assemble the



- Mount the Twist n' Flow control in a suitable loca-1. tion by drilling a 1-3/8" diameter hole in the tub.
- 2. Silicone the flange of the control and assemble the nut hand tight.
- 3. Drill a 1/8" diameter hole through the port above the pump inlet (Fig. 1).
- Install the brass fitting with o-ring into the port using a 9/16" socket or wrench until the flange of the fitting is flush with the port - DO NOT OVER-**TIGHTEN!**
- 5. Attach one end of the tubing to the control or the brass fitting.
- 6. Cut the tubing to length so that it does not sag and trap water (Fig. 2).
- 7. Attach the other end of the tubing.



Figure 1

Figure 2