



## **TOUCHSTONE Air-Activated Controller** **Installation and Operating Instructions**

### **Product Illustration:**



### **Installation Instructions:**

1. Plug the Pump into the NEMA Socket on the front of the Control Box.
2. Plug the air tubing from the air button on the bathtub onto the Air Tube Nipple on the front of the Control Box.
3. Plug the Control Box into the standard wall outlet under the tub.
4. The Control Box must be installed with the nipple located in the lower right hand corner.
5. The Control Box must be installed on a vertical surface with a 6" clearance around all ventilation openings.
6. The underside tub temperature must not exceed 122°F (50°C).

**WARNING: Failure to install in strict accordance with each and every instruction above may cause the Control Box to fail, which may cause injury to persons and/or property**

### **Operating Instructions:**

The first press of the air button will start the Pump at high speed. This will also start a 20-minute countdown timer which will automatically turn off the Pump when time expires. If more time is desired after the Pump turns off automatically, press the air button again to start a new 20-minute session.

The second press of the air button will turn the Pump off manually.

**WARNING: Use and follow these instructions along with all instructions that have been provided with your whirlpool bathtub in order to fully enjoy the bathtub safely.**



## **TOUCHSTONE Air-Activated Controller** **Installation and Operating Instructions**

### **Product Illustration:**



### **Installation Instructions:**

1. Plug the Pump into the NEMA Socket on the front of the Control Box.
2. Plug the air tubing from the air button on the bathtub onto the Air Tube Nipple on the front of the Control Box.
3. Plug the Control Box into the standard wall outlet under the tub.
4. The Control Box must be installed with the nipple located in the lower right hand corner.
5. The Control Box must be installed on a vertical surface with a 6" clearance around all ventilation openings.
6. The underside tub temperature must not exceed 122°F (50°C).

**WARNING: Failure to install in strict accordance with each and every instruction above may cause the Control Box to fail, which may cause injury to persons and/or property**

### **Operating Instructions:**

The first press of the air button will start the Pump at high speed. This will also start a 20-minute countdown timer which will automatically turn off the Pump when time expires. If more time is desired after the Pump turns off automatically, press the air button again to start a new 20-minute session.

The second press of the air button will turn the Pump off manually.

**WARNING: Use and follow these instructions along with all instructions that have been provided with your whirlpool bathtub in order to fully enjoy the bathtub safely.**