



Important Safety Instructions

**PLEASE READ CAREFULLY PRIOR TO
Troubleshooting and Servicing Electrical Equipment**

Definitions:

WARNING (May cause serious injuries or death)

CAUTION (May cause property damage)

For information on NuWhirl Instructions, see:
www.nuwhirl.com/docs/product-instructions.html

When installing and using this electrical equipment, basic safety precautions should always be followed, including:

WARNING: Keep dry. Replace control if exposed to water, moisture or contamination.

WARNING: Use and follow these instructions along with all instructions that have been provided with your whirlpool bathtub in order to fully enjoy the bathtub safely.

WARNING: Electronic control system components should be installed as per local and national Electrical Codes, in a location not to be subjected to splashing or flooding. Exposure to water or splashing will void all product certifications and warranties.

There are no user serviceable parts inside. Opening, modifying, or tampering with control system components will void all product certifications and warranties.

WARNING: Risk of electric shock. Connect only to a ground type receptacle or power supply junction box protected by a Ground-Fault Circuit Interrupter (GFCI). Contact a qualified electrician if you cannot verify that the power supply is protected by a GFCI. The GFCI should be tested on a routine basis. Consult the GFCI manufacturer's instructions for correct testing and operation.

For electrical connections, see applicable wiring diagram.

See www.nuwhirl.com/docs/product-instructions.html

Do not use an extension cord to connect the product to the electric supply; provide a properly located receptacle or junction box.

WARNING: Failure to install in strict accordance with each and every instruction above may compromise the system, which may cause injury to persons and/or property.

The tub may be supplied from more than one power source. Before working on any electrical device, make sure all power to the control system is off.

Use this unit only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer. Any improper installation or misuse of the equipment may result in injury to the user and will void the warranty.

Save these instructions.



Installation

1. The blower must be installed by the manufacturer of the whirlpool bathtub prior to shipping the bathtub.
2. Install the blower on a flat horizontal surface using appropriate hardware.
3. To reduce noise, provide or install vibration resistant pads underneath the blower mounting feet.
4. Connect the outlet piping to the blower: If the blower has a slip-socket, insert the piping and secure with the supplied clamp. Do not glue the pipe into the socket. If the blower has a threaded outlet, hand tighten the union nut to the blower. The o-ring in the union is all that is necessary to secure a leak-free joint, do not use any Teflon tape or pipe joint compound on the threads of the union.

BLOWER WIRING

1. **Make sure power is off from the source before installation.**
2. The blower must be wired for the proper voltage by a licensed electrician in accordance with all applicable electrical codes.
3. The voltage, ampere draw, and frequency are listed on the blower nameplate—DO NOT EXCEED NAMEPLATE VOLTAGE.
4. Install an outlet receptacle or junction box (depending on the power cord configuration supplied on the blower) within range of the power cord.
5. The conductors to supply power to the outlet receptacle or junction box must be large enough to carry the necessary amperes for the required length without excessive voltage drop.
6. The power to the blower should be on a dedicated branch circuit that is protected by a Ground-Fault Interrupter Circuit (GFCI). The GFCI should be readily accessible for routine operational testing.
7. All internal wiring has been completed at the factory. No additional wiring is required in the terminal box compartment.
8. The metal enclosures of all electrical components, current collectors, and other metal in contact with the tub water shall be bonded together with individual solid copper bonding conductors not smaller than #8 AWG. A bonding lug for this purpose is provided on the blower, if required.

Service

The blower has been designed and tested to give trouble-free operation over the lifetime of the bathtub. If the system does not operate as described, stop the blower and contact the bathtub manufacturer or supplier.

Do not attempt to service the blower. There are no field replaceable parts.

Any service performed on the whirlpool system must be performed by a qualified service technician in accordance with applicable codes. Before working on electrical equipment, be certain that the power is off at the source.

Replace blower with a blower of equal power. Changing the power of the blower (higher or lower) may adversely affect the performance of the blower and the whirlpool system.

Cyclone Blower

Owner's Manual

Operating Instructions

Your blower equipped whirlpool system is operated by separate controls. An operating manual should have been provided to you with those controls to explain their specific operation.

In general, the blower may be controlled by either an air button or a keypad on the bathtub.

With an air button control, the blower may function as a single or multi speed unit. If the control is single speed, subsequent presses of the button will turn the blower on and off at full speed. If the control is multi speed, either successive presses of the button will activate the different speeds of the blower before turning the blower off, or a press and hold action will vary the speed of the blower. With multi speed controls, a "Massage" or wave mode may be included where the power of the blower is alternated between full power and low power.

With a keypad control, the blower may function as a single, but more likely, multi speed unit. The action of the keys may require press and release or press and hold actions to perform functions. A key with a "+/-" symbol may be provided to raise or lower the power of the blower.

Such controls may include timer functions that will typically turn the blower off after 20 minutes of run time.

In nearly all cases the control will include a "dry cycle" or "purge" function. This is a preset function that will automatically turn the blower on for a short period of time at a set interval after the blower has been turned off (either manually or by the timer function).

This short period of running the blower will act to purge out, or dry out any residual water that is in the caps of the air inlet fittings and/or the air supply lines feeding them. This is a desirable feature to keep the system clean and fresh and is an intended function of the system that should not cause any concern or alarm.

Again, the operating examples above are generalizations, the specific operation of your system may be different, and a separate manual should have been provided to explain their exact operation.

WARNING: Blower systems must be properly configured (sized) based upon the specifications of installed system components and must not exceed the max PSI rating for each model blower as published by NuWhirl. Failure to do so may cause the blower to over-heat and shut down or cause damage to system components or property or persons.

Retain this manual for future reference

**For your records and future reference
please fill in data below:**

Manufacturer: _____

Model: _____

Serial: _____

Date of Installation: _____

