




Multi-Color Tub Light CICL-297-01-01-01 Installation Instructions

CICL-297-01-01-01:

PARTS LIST

- Light Housing and Lens
- Gasket
- Backing nut


Use of Approved Silicone for install is optional.



Follow the steps below to

STEP 1

Drill a 1-5/16" Hole on the tub and place supplied gasket against the back of the surface Lens. Install the CICL-297 on the tub.



STEP 2

Install backing Nut and tighten by hand force only.



WARNING
DO NOT USE TOOLS.



STEP 3

Connect 4 Wire cable (CCBL-366) to Light as shown (see **Picture #1**). This Light can also be daisy chained from 2 to 4 Lights (dependent on main control unit) by using additional cables (CCBL-366) see **Picture #2**

[Picture #3 displays incorrect way of connecting the cable (CCBL-366) **Do not connect backwards**]



WARNING:

1. If opting to use silicone instead of the supplied gasket, use only the following silicones that have been approved: DOW-CORNING 700 or GE 2801 (**using the wrong silicone may cause damage to the Light Housing.**)
2. Connect cables to Light as shown above. Installation may not require the use of both connections on LIGHT. **Failure to connect cables to LIGHT as shown may cause damage.**